



Supreme Heating

Our Innovation. Your Lifestyle.



YOU WILL REQUIRE A REPAIR KIT WHICH INCLUDES:

- Collector
- Pressure Sleeves
- Joining Barbs
- Grommets

Supreme Instructions: Repairing a Broken Barb



STEP 1: Strip the collector back and cut the end of the broken barb just below the joining barb to remove it.



STEP 2: Drill out the hole using a 8.5 - 8.7mm drill bit. Be careful if the drill bit is new.



STEP 3: Clean the hole to remove any excess materials.



STEP 4: Place a grommet into the cleaned hole.



STEP 5: Lubricate the hole and insert a joining barb.



STEP 6: Peel the excess collector back to expose a single strip.



STEP 7: Place a pressure sleeve over the strip. Apply a lubricant onto the barb and push the strip onto the barb.



STEP 8: Push the pressure sleeve down over the strip to secure.