



Supreme Heating

Our Innovation. Your Lifestyle.



YOU WILL REQUIRE A REPAIR KIT WHICH INCLUDES:

- Collector
- Pressure Sleeves
- Joining Barbs
- Grommets

Supreme Instructions: Repairing a Hole in the Collector



STEP 1: Squeeze the collector upward to expose the hole in the collector.



STEP 2: Cut the webbing between the tubes on either side of the hole.



STEP 3: Expose approximately 5cm of collector around the hole.



STEP 4: Cut the collector on either side of the hole to remove it.



STEP 5: Place a pressure sleeve on either side of the collector.



STEP 6: Push a joining barb onto one of the sides. Using a lubricant will make this easier.



STEP 7: Push the other side of the collector over the joining barb to connect the two sides.